



SERVICE SCHEDULE



IMT GREASE LUBRICATED AXLE TYPES F22, FE22, FE24

SERVICE SCHEDULE		Periodic checks		
Which ever comes first >	Mileage intervals	After first 5000kms	Every 30,000km	Every 120,000km
	Time intervals	After first month	Every 3 months	Every 12 months

INSPECTIONS

Remove hub cap and inspect grease around outer bearing and in hub cap for contamination				●
Clean and repack bearings and hub with fresh grease				●
Check condition of taper roller bearings, Replace if necessary				●

*original equipment uses SAF Li Lube grease

GENERAL for wear / damage

Check wheel bearings for excessive play, adjust as required (Min 0.25, Max 0.16mm)	●	●		
Check hubs for correct rotation, loss of lubricant and free of bearing noise	●	●		
Check brake linings for wear	●	●		
Check brakes for correct adjustment	●	●		
Check braking system for air leaks	●	●	●	
Check truck-trailer combination for brake compatibility	●			●
Check calipers for free movement	●	●		

Special service conditions;

Vehicles operating in off highway / harsh conditions; service at suitably reduced time intervals to suit the vehicle operation